Instructions for installation Pillar IKI 7,5 and 9 kW **Wave control unit**

Embedding the control panel inside a wall: Width of slot: 70 mm Height of slot: 70 mm Depth of slot: 65 mm

Do not remove the orange plastic protection cover on the back of the panel.

Affixing the sensor to the ceiling: distance from heater frame 100-300 mm

The temperature sensor should be installed no less than 1000 mm from an undirected air vent income, or less than 500 mm from a directed air vent.



